

Care & Maintenance

Hospital-Grade USB Wall Charger

U280-001-W2-HG



WARNING: Do not spray with liquid cleaning products.

- To clean, unplug unit and wipe with a clean cloth. Cloth may be dampened with an all-purpose cleaner.
- Ensure mechanical integrity of case.
- Ensure mechanical integrity of power prong. It should be free of dents or exposed wires/conductors.
- Tripp Lite recommends annual inspection of its products when used in a typical hospital, medical, healthcare or assisted living environment.



1111 W. 35th Street, Chicago, IL 60609 USA • www.tripplite.com/support

Copyright © 2019 Tripp Lite. All rights reserved.